
D (-COM. DEFLECTION)
TO L ASS'Y L5 BOARD
TO L ASS'Y L5 BOARD
CN5820
CN5821
CN5822
CN5823
CN5824
CN5825
CN5826
CN5827
CN5828
CN5829
CN5830
CN5831
CN5832
CN5833
CN5834
CN5835
CN5836
CN5837
CN5838
CN5839
CN5840
CN5841
CN5842
CN5843
CN5844
CN5845
CN5846
CN5847
CN5848
CN5849
CN5850
CN5851
CN5852
CN5853
CN5854
CN5855
CN5856
CN5857
CN5858
CN5859


CONNECTOR
RANEL
HD15
5BNC
TO D BOARD
CN511
CN402
CN401
R IN 2
R GND 2
G IN 2
G GND 2
NC
B IN 2
B GND 2
R IN 1
R GND 1
G IN 1
G GND 1
B IN 1
B GND 1
IC401
M52755FP RGB PRE-AMP
IC402
M52722FP RGB DRIVE
IC403
FA4111
RGB OUT
C BLOCK
V901
PICTURE
TUBE
TO D BOARD
T902 (FBT)
FBT
CN1
CN2
KB
GND
KG
KR
HEATER +
CN403
CLP
LOWB_DET
C.BLK
GREEN
INPUT SW
VIDEO
TO D BARD
CN506
CN407
ASC_SW
OSD_SEL
MOSI
CLK
DAC_SEL
HFBP
VRET
TO D BARD
CN503
CN405
+200V
NC
+80V
GND
+15V
STBY+8V
GND
NC
HEATER+
TO G BOARD
CN672
CN406
1KV
N.C.
TO D BOARD
CN507
IC404
NJM7815FA
12V REG
IC408
TA78L05S
5V REG
IC405
M62332GP-FSED
D/A CONVERTER
IC406
LSC4850W2AR2
OSD
A or A3
(VIDEO AMP. RGB OUT)











Note: L complete board and L3 complete board have interchangeability though it is a little different because the material of the circuit board is different.